

BATTEN FIX

WARNING: PLEASE TURN POWER OFF BEFORE INSTALLING.

1



BATTEN HOLDER:
You must have a batten (globe) holder in your ceiling to install a DIY fitting.

SHADE:

Unscrew lower portion of batten holder (skirt)
Insert the shade over the batten holder.



2

3



SKIRT:

Place the skirt through the shade and screw into batten holder.

4



GLOBE:

Insert globe into lampholder in fitting, ensuring globe is secure.

4 SIMPLE STEPS TO INSTALL